tinyloops.com - Programming the Roland TB-303

STOP				
pattern	-	select	:	[1..8], A or B
	-	chain	:	[1..4] or [5..8]
	-	shift info	:	hold "PITCH MODE"
	-	shift	:	hold "PITCH MODE" + [C..C']
general	-	tune	:	hold "TAP" for sustained pitch

RUN					
pattern	-	select	:	[1..8], A or B	
	-	chain	:	[1..4] or [5..8]	
	-	shift info	:	hold "PITCH MODE"	
	-	shift	:	hold "PITCH MODE" + [C..C']	
	-	mangle		press TAP	tuning pitch will sound *after* RUN/STOP is pressed yes that is useless ;)

Programming the Roland TB-303

pattern play
when the 303 is slaved to a master (eg the TR-606), the RUN/STOP key is disabled on the 303. please use the RUN/STOP key on the master.

PATTERN PLAY

functional buttons (the greyed out buttons do not respond):